

# Amigo Clean-out solution

## Mild alkaline clean-out solution

The non-image areas of an Amigo TS plate are easily removed by immersing the plate in the liquid and by application of a slight pressure of the brush roller. This is a PHYSICAL PROCESS as opposed to the conventional wet chemical process for ‘traditional’ digital plates. Once cleaned by the clean-out solution, the plate is rinsed by passing through the wash section and gummed by passing through the processor’s gum section.



### Working instructions

#### Special Comments

- Gum to be used in combination with the clean-out solution is RC795 or RC795A

#### Main characteristics

- Alkaline solution
- Non solvent based
- Low replenisher rate
- Ready to use



### Compatibility

#### Plate

- Amigo TS
- Amigo TS baked



## Storage

- Store at room temperatures in a dry, well ventilated area.  
#
- Keep away from heat and direct sunlight
- Keep the containers closed.
- Shelf life: 24 months from date of manufacture



## Ordering information

- Art. code 1000 litres: 4NCJH
- Art. code 20 litres: EP2EZ
- Art. code 2x200 litres: PYPMZ



## Waste

- Collect if possible.
- Send to authorized disposal centres.
- Follow local and national regulations.



## Safety

Read the Material Safety Datasheet ([MSDS](#)) before using this product.